

Modèle : Soundbird B10

FRANÇAIS

LAMPE LED AVEC ENCEINTE INTÉGRÉE

Manuel d'utilisation



Aquila®

INTRODUCTION :

Félicitations pour l'achat de votre Soundbird B10.

C'est un produit fiable et testé conçu par Aquila. Nous espérons qu'il vous apportera beaucoup de plaisir et rendra vos moments du quotidien plus simples et plus amusants.

INCLUS :



Soundbird B10

+



Manuel d'utilisation

+




Cable de charge Type-A vers Type-C

CARACTÉRISTIQUES :

- **Version Bluetooth :** v.5.3
- **Distance de Communication :** <10 mètres
- **Autonomie en lecture musicale :** 12h (à 50% du volume)
- **Haut-parleur :** 52mm / 10W*2
- **Temps de charge :** 5,5 h
- **Capacité de la batterie :** 10 000 mAh / 3,7 V
- **Tension de charge :** DC 4,7 ~ 5,5 V
- **Puissance nominale :** 20 W

COMMANDES :



1. Bouton d'alimentation

- Appuyez longuement pendant 3 secondes pour allumer/éteindre.
- Lorsque l'appareil est allumé pour la première fois ou lorsqu'aucun appareil n'est connecté, il entre automatiquement en mode appairage.
- Appuyez brièvement : répondre/mettre fin à un appel, lire/mettre en pause la musique.

2. Bouton de volume -

- Appuyez brièvement sur le bouton de volume : diminuer le volume.
- Appuyez longuement sur le bouton de volume : passer à la piste précédente.

Comment appairer plusieurs enceintes :

- Déconnectez votre téléphone de l'enceinte.
- Maintenez enfoncé le bouton 3 (Mode) sur les deux enceintes en même temps. Les enceintes annonceront alors "pairing mode".
- Gardez les boutons enfoncés pendant trois secondes jusqu'à ce que vous entendiez un "bip".
- Reconnectez votre téléphone à l'enceinte principale (Soundbird), et vos enceintes TWS sont prêtes à fonctionner.

Comment appairer votre téléphone :

- Maintenez enfoncé le bouton marche/arrêt de l'enceinte pendant 3 secondes.
- Accédez à vos paramètres Bluetooth sur votre appareil et connectez-vous au Soundbird.

Remarque : Lorsque vous connectez deux enceintes Soundbird ensemble, il est important de ne pas être connecté à votre téléphone en même temps.

3. Bouton de source

- Appuyez brièvement : Changer la source du son (Bluetooth, AUX, carte TF).
- Appuyez longuement : Connexion de deux enceintes Soundbird en appairage TWS. (Remarque : Déconnectez votre téléphone avant l'appairage.)

4. Bouton de lumière jaune

- Appuyez brièvement : Allumer la lumière.
- Appuyez plusieurs fois pour passer entre les trois modes d'éclairage.
- La 4e pression courte éteint la lumière.
- Appuyez longuement (> 8 secondes) pour réinitialiser et éteindre l'appareil.

5. Bouton de lumière multicolore

- Appuyez brièvement : Allumer la lumière respirante (avec des couleurs changeantes).
- Appuyez brièvement une deuxième fois : Fixer la lumière respirante en une couleur unie.
- Appuyez longuement : Éteindre la lumière respirante.

6. Bouton de volume +

- Appuyez brièvement sur la touche de volume : augmenter le volume.
- Appuyez longuement sur la touche de volume : passer à la piste suivante.


Port de charge :

Rechargez votre Soundbird via la connexion USB Type-C.

Utilisation en mode batterie externe :

Rechargez votre téléphone ou un autre appareil en utilisant la batterie intégrée. Il suffit de connecter votre appareil au port USB Type-A.

PRODUCT DIAGRAM:



VOICE PROMPT 1:

Incomming call	Mirror the phone's preset signal.
When your phone is establishing bluetooth connection	Connected
Low battery (less than 15% battery)	Ticking sound
Answering	No beep
Maximum volume	Beep
Turn on the phone	Power on

VOICE PROMPT 2:

Pairing	Ding Dong
Ending the call	No beep
Turn off the phone	Power off
Volume up / down	No beep
AUX / TF / Bluetooth mode	Line in/ Music/ Bluetooth mode

AUDIO LED INDICATOR STATUS:

Charging	Red light flashing
Bluetooth connection / TF card / AUX input	Continuous Blue light
Volume plus / previous song	
Power on / mode / light button	White light long light 15 seconds off
Volume down / next song	
Fully charged	Continuous Red light
Start up	Blue light blinking
Shutdown	Blue light out
Matching search status	Blue light blinking

TIPS:

1. Do not attempt to disassemble or replace any parts inside the product.
2. Do not put the product into water or any other liquid, this product is not designed to be waterproof.
3. If any liquid accidentally enters the product, please immediately disconnect and remove the product.
4. To avoid electric shock, please make sure there is no water on your hands when installing or uninstalling the product.
5. Do not place this product near a heat source or expose it directly to a fire source.
6. Do not place this product in an environment where there is a strong electromagnetic force, as this may cause the product to malfunction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



NEED THE MANUAL IN LOCAL LANGUAGE?

Visit aqiila.eu and download the manual to your device.

Get in touch: www.aqiila.eu | hello@aqiila.eu

Contact: GPBM Nordic AB | Sörredsvägen 113 | 418 78 Göteborg | Sweden

Contact: Brands Services B.V. | Florijn 14-16 5751 PC Deurne | The Netherlands